# 1969 MUSTANG CIRCUIT DIAGRAM

R MARKER LIGHT
DIRECTION SIGNAL
PARKING LIGHT
LOW BEAM
HIGH BEAM
HORN
BATTERY
STARTER RELAY
STARTER
ALTERNATOR
COIL
TEMP GAUGE (ENG.)
I A S F
ALTERNATOR REGULATOR
TO HEATER RESISTER & BLOWER MOTOR
FUSE BLOCK
BACKUP LIGHT SWITCH
NEUTRAL SAFETY SWITCH
STOPLIGHT SWITCH
SEATBELT WARNING SWITCH
OIL PRESS SWITCH
WINDSHIELD WIPER MOTOR
LOW BRAKE WRNG SW
WINDSHIELD WASHER MOTOR
L MARKER LT
R DOOR SWITCH
EMERG FLASHER
FLASHER
BLIND CIRCUIT
R DOOR COURT LIGHT
R COURTESY LIGHT
GLOVE BOX LT
HEATER SWITCH
HEATER LT
MAP LIGHT SW
MAP LIGHT
CIGAR LIGHTER
CLOCK LIGHTS
CLOCK IGN SW LIGHT
IGNITION SWITCH
PRDNL LIGHT
DIRECTION SIGNAL & HAZARD SWITCH CONNECTOR
SEAT BELT WARNING LIGHT
TACHOMETER
ALT IND
ALT IND
BRAKE WRNG LT
CONSTANT VOLT REG
BREAK WRNG LT
GAS GAUGE
TEMP GAUGE
OIL PRESS IND
AMMETER
AMMETER GROUND
R DIRECT IND
HIGH BEAM IND
GROUND
L DIRECT IND
INSTR LIGHTS
WINDSHIELD WIPER SWITCH
LIGHT SWITCH
L COURT LT
R DOOR COURT LIGHT
PILLAR LT
PILLAR LIGHT
DOME LIGHT
R MARKER LT
STOPLIGHT & DIRECTION SIGNAL
TAIL LIGHT
R BACKUP LIGHT
TRUNK LT & SWITCH
LICENSE LIGHT
GAS GAUGE (TANK UNIT)
L BACKUP LIGHT
TAIL LIGHT
STOPLIGHT & DIRECTION STOPLIGHT
L MARKER LT

Report Errors or Omissions to gwflew@gmail.com

Colorization by:
www.clanmcmuffin.com/Mustang.html
rev 11/02/2023